

READ SAFETY DIRECTIONS AND SHAKE WELL BEFORE OPENING OR USING

HomeGuard[®] Protectacote

Primer

Usage Direction: Apply a single coat to run of masonry, concrete or fibre board prior to applying HomeGuard Protectacote Termite and Waterproof Barrier. All surfaces must be clean and free of grease and dirt before application.

Coverage: 10sqm per 1litre

Drying Time: Allow 15mins (in ambient conditions) before applying HomeGuard Protectacote Termite and Waterproofing Barrier.

Equipment: HomeGuard Protectacote Primer can be applied by brush, roller or spray gun.

Cleaning Equipment: Equipment used to apply HomeGuard Protectacote Primer can be cleaned with water. Clean equipment without delay.

Safety Directions: Wear eye protection when spraying.

First Aid: Hold eyes open and flush immediately with large amounts of water. If irritation persists seek medical attention.

Contents: 5L

Batch No:

DOM:

FMC Australasia Pty Ltd
Level 2, Building B, 12 Julius Ave, North Ryde, NSW 2113
Contact Number: 1800 066 335

FMC

FMC, HomeGuard and Protectacote are Registered Trademarks of FMC Corporation, Philadelphia, USA.